



Managing *Botrytis*-infected fruit



What is *Botrytis cinerea*?

Botrytis cinerea is a weather-driven fungus which causes the grapevine diseases botrytis, bunch rot and grey mould. High humidity or prolonged rain in conjunction with cool or mild temperatures results in persistent moisture on berry surfaces and promotes infection and disease development. Previously infected sites and sheltered vineyard areas such as hollows are at greatest risk of developing the disease.

What are the implications for winemakers?

Managing *Botrytis* in the vineyard can be a challenge because many factors contribute to infection and disease development. For winemakers there are two main reasons to be concerned about *Botrytis*-infected fruit. First, *Botrytis* produces the enzyme laccase, which in the presence of oxygen can cause oxidative

spoilage. Second, *Botrytis*-infected fruit can result in a mouldy character in wine. Preventing laccase from causing damage requires techniques that minimise or eliminate exposure to oxygen.

Botrytis-infected red grapes will require different treatments to white grapes. The following processing strategies will help reduce the issues that can be caused by *Botrytis*-infected fruit.

Strategies to use for both red and white grapes

- Minimise the quantity of mould-affected fruit at harvesting. For crops picked by hand, fruit can be selectively harvested and infected fruit avoided. Pickers must be able to recognise *Botrytis* bunch rot and know which bunches should be avoided. If the vineyard is to be machine-harvested, hand pickers can be used to remove the



- worst affected fruit prior to machine harvesting.
- Add more sulfur dioxide (SO₂) than usual (in the range of 60-100 mg/L depending on severity) due to the increased risk of oxidation from laccase (although SO₂ does not inactivate laccase) and because there is likely to be a higher than usual population of other unwanted microorganisms if *Botrytis* is present.

Strategies for processing white grapes

- Whole bunch press with CO₂ cover. Assess press fractions for mouldy taint carefully.
- Add pectic enzyme at the higher end of the recommended range and cold settle at low temperature to achieve rapid settling. Extra additions of pectic enzyme might also be required if settling.
- Rack and discard the heavy lees.
- Trial bentonite additions to remove mouldy characters and settle for 24 hours. Recommended starting rate is 0.5 – 1 g/L bentonite.
- Rack off bentonite lees.

Strategies for processing red grapes

- Minimise the time between crushing and inoculating. Avoid cold soaking.
- Add a greater than usual yeast inoculum as a sacrificial culture to assist with binding of free SO₂.
- Consider adding 200-500 mg/L of an oenological tannin at crushing to bind the laccase enzyme (note that tannin addition can change wine style).

- Where practical, separate heavy fermentation lees at pressing, using the carbon dioxide (CO₂) produced during fermentation for coverage, and press to stainless steel not oak.
- Rack off gross lees after 24 hours and test for laccase activity. If laccase activity is still detected in the wine after subsequent racking, heat treatment of the wine might be necessary.
- Consider the use of a suitable enzyme to assist with clarification and filtration. Red wines made from *Botrytis*-affected grapes are often difficult to clarify and filter due to the presence of long chain polysaccharides.

Qualitative test for laccase activity

A simple bench test can be used to obtain a qualitative result. Sulfur dioxide is added to the sample in question to give a total SO₂ concentration of about 60 mg/L. The sample is then poured into two wine glasses (approximately 50 mL of sample in each glass) and each glass is covered with a watch glass or petri dish lid. One sample is placed in a refrigerator, while the other sample is left 'on the bench'. The samples are examined after 24 hours and compared for any change in colour or quality. If there is laccase activity, the sample left on the bench should be browner than the sample left in the fridge and may have an oily film on the surface of the wine.



After 24 hours:




Fridge sample

Bench sample

Quantitative test for laccase activity

Quantitative determination of laccase activity can be achieved using a number of commercially available test kits. AWRI Commercial Services performs simultaneous quantitative and qualitative analysis for laccase activity.

If laccase activity is detected, heat treatment (pasteurising) should be considered to deactivate the laccase enzyme before conducting the fermentation. It is recommended that the juice be pasteurised at a minimum temperature of 65°C for 40 seconds and wine at a minimum temperature of 65°C for 20 seconds.



Deactivating the laccase enzyme is a time and temperature relationship, where the higher the temperature, the shorter the amount of time required for deactivation to occur. Graph prepared from data provided by Dr Roger Boulton (pers. comm.)

If heat treatment is not available, initiate fermentation. Addition of 0.1 – 0.2 g/L of bentonite during fermentation might be beneficial.

As SO₂ can inactivate thiamine, the addition of thiamine to the must should be considered.

The lees will contain much of the laccase, so it is important to rack off fermentation lees as soon as possible after the fermentation is complete, and keep wine in stainless steel with inert gas cover.

Test wine for laccase activity: if positive, further racking can be beneficial in order to remove all fermentation lees. However, if laccase activity is still detected in the wine after subsequent racking, heat treatment of the wine might be necessary.



Acknowledgement

This work was supported by Australia's grapegrowers and winemakers through their investment body Wine Australia, with matching funds from the Australian Government. The AWRI is a member of the Wine Innovation Cluster.

Further reading

Boulton, R.B.; Singleton, V.L.; Bisson, L.F.; Kunkel, R.E. 1996. *Principles and practices of winemaking*. New York: Chapman & Hall: 459.

Godden, P. 2000. Bunch rots - understanding the winemaker's dilemma. Davies, C., Dundon, C., Johnstone, R. (eds.) *Managing bunch rots: proceedings of a seminar; 28 July 2000, Mildura Arts Centre, Mildura, Victoria*. Australian Society of Viticulture and Oenology: Adelaide, SA: 52-54.

Godden, P. 2000. Management of various vineyard-derived moulds during winemaking. *AWRI Technical Review* 129: 13-17.

Leske, P. 1993. Laccase - A threat in 1993. *Aust. N.Z. Wine Ind. J.* 2: 122-124.

Somers, T.C. 1984. *Botrytis cinerea* - consequences for red wines. *Aust. Grapegrower Winemaker* (244): 80, 83, 85.

Contact

For further information, please contact:

AWRI helpdesk

Phone 08 8313 6600 **Fax** 08 8313 6601

Email helpdesk@awri.com.au

Website www.awri.com.au

Address Wine Innovation Central Building,
Corner of Hartley Grove & Paratoo Rd,
Urrbrae (Adelaide), SA 5064